



Now Standard  
on 8' and 16'  
S31, S32,  
S31 UVD,  
S32 UVD




1  
Roll out till you reach the fold in the blanket

2  
Grab the fold and pull

3  
Pull till blanket is fully extended

4  
Straighten with adjoining roll



Distributed by



EROSION CONTROL, LINERS, GEOTEXTILES, BMP'S & SWPPP'S

MFG BY



Erosion Control  
BLANKET